

FLOVCODE Smarter programming

Datasheet



Contents

1. What is Flowcode	3
2. Flowcode design flow	4 - 5
3. Advantages of using Flowcode	6
4. Flowcode overview	7
5. Flowcode 7 features	8 - 10
6. Flowcode support	11 - 13
7. Flowcode licensing	14 - 15
8. Flowcode 7 components	16
9. Flowcode 7 target specifications	17 - 18



What is Flowcode?

Flowcode allows users to develop complex electronic and electromechanical systems with ease.

Flowcode is an advanced integrated development environment (IDE) for electronic and electromechanical system development. Engineers - both professional and academic use Flowcode to develop systems for control and measurement based on microcontrollers or on rugged industrial interfaces using Windows compatible personal computers.

A 2D and 3D graphical development interface allows students to construct a complete electronic system on-screen, develop a program based on standard flowcharts, simulate the system and then produce hex code for programming a range of devices including

The state of the s


- Flowcode's graphical programming language makes it easy for those with minimal programming experience and gives professional engineers a fast environment in which to develop complex systems.
- Users are fully supported through the Matrix forums, a range of free resources including a wiki-site, and through the opportunity to take advantage of Matrix's professional services.
- Code-porting is made easy with Flowcode, as users can work with multiple target devices and can easily switch devices midway through their projects.

Microchip's PIC MCU; 8bit, 16bit and 32 bit, as well as Atmel AVR, Arduino and ARM devices.

Flowcode version 7 has a number of new developments which combined, provide a fast and effective way software for writing complex projects for embedded systems. With a flexible licencing structure, including a free version of Flowcode, which is excellent for learning programming, developing applications at home or for prototyping designs, users can build a bespoke licence perfect for their embedded system development requirements by visiting www.matrixtsl.com. This datasheet presents a number of features and advantages of using Flowcode, support and licencing information plus further info on target device support and components that can be found in the latest version.




Flowcode 7's easy-to-use and modern UI is perfect for developing electronic systems for users in education or developing professionals.



Flowcode 7's boasts a range of brand new features (including code profiling) which make it the development environment of choice for thousands of academic institutions worldwide and thousands more professional engineers.


Design

Electronic engineer




Design a virtual circuit board with PCB level components that connect to a virtual microcontroller and develop the program using flowcharts.

Simulate




Simulate the program and circuit board components to check function using LEDs, displays to see function and interacting with virtual switches to control the system.

Electromechanical engineer




Develop a mechanical system in Solidworks and characterise it for Flowcode. Develop a flowchart program for control and operational data conditioning.




Simulate the mechanical system, the electronic system and the data decoding algorithms all in one package.

Test engineer



Develop a mathematical and/or physical model of your system, and develop a flowchart control program using Flowcode.




Use Flowcode Dashboard objects to simulate system performance in human friendly graphical format.




Test



Download to the microcontroller in the E-blocks development system and use In-Circuit-Test and Softscope feature to verify operation at pin level.




Use In-Circuit-Test to test and debug at a pin level.



Link Dashboard objects, Softscope and Console to third party instruments using DLLs in SCADA fashion to verify performance in real time.

Deploy



Develop the final circuit board and release to market.



Develop the final product, verify operation and release to market.



Deploy your system in a control system based on microcontrollers, MIAC controller or Windows PC linked to third party controllers using DLLs.


Advantages of using Flowcode

Flowcode software is based on standard flowchart symbols. Flowchart icons can be compiled to a microcontroller and can be executed on a Windows PC. The PC-side software in Flowcode includes a full suite of Windows commands for mathematics, controlling graphics on the monitor, communications via Ethernet etc. In fact Flowcode includes a full Windows programming language as well as a microcontroller compiler.

This PC-side and chip-side functionality makes Flow-code really powerful:

 Complex systems can be designed and simulated before chip-side compilation which saves design time.


- In-Circuit-Test data can be linked to simulations to show system performance at run-time which proves designs function properly.
- Programs can be deployed on a microcontroller or a Windows PC.



5 reasons for using Flowcode 7:


- It's easy-to-use: Flowcode's graphical environment makes it a perfect tool for teaching embedded systems or developing complex designs.
- 2. Advanced test & debugging features: including simulation, code-profiling and Ghost technology allows users to make use of in-circuit-test (ICT) and in-circuit-debug (ICD) features including a built-in oscilloscope and data recorder.
- 3. Non-programmer friendly: mechanical engineers, test engineers, chemical engineers and just about any other engineer working with microcontrollers can easily develop systems for MCU's.





- 4. Microcontroller flexible: with support for a host of PIC devices as well as Atmel, Arduino and ARM MCU's, Flowcode gives you a broad range of target devices for your development needs. Code-porting is also easier than ever before.
- 5. It's FREE: users who do not require commercial or academic rights, additional features or full device support can use the free version of Flowcode 7 for developing applications at home or to prototype designs.





- Icon tool bar drag and drop standard flowchart icons onto your flowchart. Click to edit properties for a syntax-correct program.
- 2. **Project explorer** instantly see all the ports, macros, variables, constants and components in your project.
- **3.** C code program monitor the C code equivalent of your flowchart; as fast, syntax correct code is generated automatically on a per icon basis.
- **4. Control tool bar** use the standard tool bar for editing your program and also for stimulating your program and running In-Circuit-Debug / Test.
- **5. Component tool bar** choose your electromechanical component from our large library of parts; from simple switch to Bluetooth module.
- 6. Flowchart program drag, drop and edit standard flowchart icons to create a program. Design flowchart macros that can be called from other icons. Use Flowcode's powerful PC-side language to control external instruments, and monitor your systems.
- **7. Properties editor** see and edit the properties of all components.

- **8. Component debug** see the API calls in your program and component design.
- **9. Icon list window** for search results, error messages, breakpoints and bookmarks.
- **10. Analogue window** see the state of the analogue inputs in your design.
- 11. System panel design your system using the multi-view system panel. Use off-the-shelf electromechanical components or design your own. Import your model from a program like Sketchup or Solidworks.
- **12. Dashboard panel** control and monitor your program in simulation and In-Circuit-Test. Write programs using simulation API commands to show real world equivalents of your data in human-friendly formats.
- **13. Data recorder** use this to show timevarying signals in your system. Link the scope to simulation data or real data during In-Circuit-test.
- **14. Chip** use the chip window to view and control the status of the inputs and outputs on your chip in simulation and In-Circuit-Test.
- **15. Oscilloscope** another important debugging tool that displays important data from your project.



Graphical programming

Simple, flowchart icons

The graphical icons which are used to develop your system within Flowcode are easy-to-use. If you're a first time developer or have little experience of developing electronic systems, Flowcode will make it easy for you to pick up the fundamentals and run with your designs. For version 7, users can also now customise their projects with colour coded sections, to make complex projects easier to navigate.

Fast system development



Programming can be a complex, drawn out pro-cess and can often and easily result in errors. Ensuring your code is accurate and precise takes skill and time. With Flowcode, your job becomes easier. Program's that previously took hours to design and perfect can be brought together in minutes.

Learn and program using code

If you're more advanced in your understanding of programming, or have pre-written code you want to embed into your design, Flowcode allows you to do just that. What's more, if you're using graphical icons, you can view and learn code side-by-side with your design, meaning academic users of Flowcode develop their learning over time.



Testing & debugging

Ghost Technology

Ghost Technology is an advanced way of testing and debugging your electronic system. Using Matrix's E-blocks hardware (EB006v9 and EB091, PIC and dsPIC multi-programmer boards), you can monitor every pin on your microcontroller and monitor and interpret serial data inputs and outputs. Flowcode includes an in-software oscilloscope and data recorder which displays feedback and information live from the hardware you're using after compilation.

| SINCE | SINC

Simulation debugger

For many engineers, a key requirement is to en-sure the designs you have developed will work when you compile to your microcontroller. Flowcode allows you to do all you need in simulation (see page 9) using the simulation debugger which becomes active during simulation and is used to monitor both the values of the variables in your program and the macros which are being called.

Code profiling



Code profiling is a new feature that will be launched for the first time in Flowcode 7. This feature shows when icons have been 'hit' during a simulation run, highlighting sections of code that may be deemed redundant and other parts which are executed more often and may need optimising to improve program efficiency.



Simulation

Create simple designs

You can use the Flowcode system panel tools to create your own simple 3D models within the software itself. Test the accuracy of your program by creating a simple actuator or valve, or add simple shapes to your existing designs and use the built in API to control these creations during simulation.

Import your designs from CAD packages

Flowcode integration with third party drawing packages through support for various file formats means that you can easily import your 3D drawings and designs into Flowcode and characterise and bring their electromechanical elements to life with the advanced simulation capabilities.

Multi-view system panel

View your designs from different angles whilst simulation is taking place within the system panel. Split-screen capabilities means you can ensure you're happy with your electronic design. What's more, simulation speed means your simulation now works close to real-time - so you can verify your design 'live'.



Component library

Pre-developed components

A whole suite of electromechanical components exist in our large library of parts; from simple switches and LED's to more complex communications modules. These components are developed and grown with every release of Flowcode we launch to ensure you have what you need to develop your electronic systems.



Communications components

Communications developments forms a large part of modern day electronic education and understanding. Communications including CAN bus, Bluetooth, USB, Ethernet and WI-FI are widely studied across the globe. All of these components are available within the Flowcode environment.

NEW v7 components



Flowcode V7 contains 245 components that can be used to create a wide range of electrical and electromechanical systems. These components can also be used as a basis for creating your own components or simulations.



Supported devices

E-blocks

Use Flowcode to program Matrix's electronic modules; the perfect platform for learners, engineers and electronic system developers to quickly prototype your designs on a rugged platform. A range of programming boards and peripheral downstream boards such as input, output, communications, prototype boards and more make this the ultimate development platform.

MIAC

The MIAC range from Matrix gives electronic engineers a rugged industrial platform on which to develop their designs. With MIAC's now available not only with an 8bit PIC MCU but also 16bit PIC, Arduino and Raspberry Pi (not compatible with Flowcode), users have a rugged PLC which is easy to program and perfect for harsh, industrial environments.

Arduino

One of the major benefits of using Flowcode, is that it simplifies the programming of Arduino platforms. AVR support means you can do more with your Arduino than you ever dreamed – you can even integrate it into our E-blocks modules with our E-blocks Arduino Shields.

Microchip XC Compilers

For the first time, Flowcode will include Microchip's XC compilers in version 7. For those familiar with previous versions of Flowcode, this will improve the speed at which 8bit PIC devices compile by more than ten times compared to previous versions of the software.



8bit PIC

Flowcode provides support for the entire performance range of 8-bit microcontrollers from Microchip, with easy-to-use development tools, complete technical documentation and post design-in support through a global sales and distribution network.

16bit PIC

Flowcode also supports Microchip's 16bit family of MCU's - also known as dsPIC or PIC24 devices.

32bit PIC



New for version 7 is Flowcode's ability to support the PIC32 range from Microchip. The PIc32 family delivers 32bit performance and more memory to solve increasing complex embedded system design challenges.

Microchip templates




Another new feature of Flowcode 7 is the inclusion of templates for a number of popular Microchip development boards including the Curiosity and Xpress boards.

AVR & ARM

Atmel's AVR devices including the popular Arduino, plus a range of ARM MCU's are also supported in Flowcode 7.

For a full list of the supported microcontrollers in Flowcode 7, please see page 17.



Here, we can see the template set for a Microchip Xpress boards being programmed in simulation mode using Flowcode. Users can also them compile to the hardware device easily using USB.



Academic support and support for learners

Flowcode delivers outcomes not only in professional, industrial business but also at a number of levels of education. For many years Flowcode has delivered at further and higher education levels.

- In France, hundreds of further and higher education establishments, known as lycee techniques use Flowcode to deliver teaching of electronic system design.
- In Flemish Belgium most technical schools use Flowcode to deliver a combined course in electronics and Mechanics.
- Hundreds of 16-18 Colleges, 20 top Universities and numerous other training institutions in the UK use Flowcode.
- Flowcode is used as an educational product in over 50 countries around the world.

Students can use Flowcode for learning programming, electronic design, robotics, and pneumatics and can link programs for a range of Matrix hardware systems including our low cost Prototype and Projects boards, Formula AllCode robot, our MIAC and Automatics solutions and any third party hardware that accepts hex code for the appropriate microcontroller devices.

What's more, Flowcode also has compatibility with packages including Solidworks and DesignSpark Mechanical meaning users can characterise electronic elements and parts in their mechanical de-signs.

Flowcode is very well supported. Complete beginners will find our free online courses great for covering the basics of developing electronic systems.


Meanwhile, experts will find our examples, manuals and hardware module datasheets online invaluable.

All users will value the support offered by our engineers, valued contributors, and extended online community.

The Flowcode Wiki site provide you with a detailed glossary style overview of the aspects of the Flowcode environment broken down into relevant sections to aid in finding the knowledge you require to use Flowcode effectively.



The Matrix forum provides an in-depth community of well established, long-term users of Flowcode and new Flowcode users sharing ideas and solving problems and issues encountered whilst using the software. And is attended to and updated by our own engineers.




New for Flowcode 7 is a suit of beginner courses to help those who are new to Flowcode, get up and running with their first designs and projects. These can be accessed at www.matrixtsl.com/flowcode.





We have a range of free, pre-developed Flowcode pro-grams for you to open in the Flowcode environment itself and browse, use or further develop to your own de-sire.

Within Flowcode, users also receive a range of pre-developed templates (e.g. right). These can be customised and saved as your own template files too, allowing you to save time and investment with your pro-gram development by starting off with one of these files.



Professional engineer support

Whilst the same, superb help facilities exist for professional users of Flowcode, as those that exist for academic users (see page 11), there is also another area of support that we now offer to assist professional engineers with the services they require from additional enhanced customer support with rapid response times, training to ensure you are getting the most out of your Flowcode software, to assistance in your own internal development projects .



Wiki





Forum



Course



Examples

Professional extended services

Whether you need assistance to get you up and running with your first Flowcode project, or need some technical expertise to help speed up more complex developments using Flowcode, our team of engineers are here to help. Priced from £500 (+VAT) per project, to many users of Flowcode, this service is a valuable addition to the Flowcode package

Training

Flowcode training is offered three times per calendar year at Matrix HQ in Halifax, West Yorkshire. Alternatively, we offer all Flowcode users on-site Flowcode training, which can be delivered at your place of work/study from £800 + VAT per day + travel and expenses. We can tailor training at your site to your specified needs, or deliver our pre-defined courses.

Whilst these options already exist, plans are also afoot for us to offer a range of downloadable Flowcode 7 training courses online where users can register for a small fee and access a wealth of training material.



Enterprise licenses

Whilst the Flowcode licencing structure is defined in more detail on pages 13 and 14, it's important to understand that version 7 features multiple user professional licences for the first time. An enterprise licence is activated when a user selects more than a 1 user licence of Flowcode. When a user purchases a 5 seat licence of Flowcode, with all chip variants included, you receive £500 of professional services for your team – for example, this could be attendance at our Introduction / Advanced training courses at Matrix HO.

For more information on professional services, visit www.matrixtsl.com/professional-services or contact Matrix TSL on +44 (0) 1422 252 380.





Flowcode 7 licensing is modular and straightforward, meaning you can now get the Flowcode licence that works for you, without the requirement to get every available feature. Below, we outline how licencing works for Flowcode 7. You can follow further instructions on how to acquire a Flowcode licence at www.matrixtsl.com.

Flowcode 7 also includes a completely free version. The free version of Flowcode is designed to give home users and those wanting an evaluation version of the software, access to a feature limited version of Flowcode 7. The free version is not licenced for commercial or educational institution use.

Please note, licensing may differ when purchasing through one of our official distributors. For more specific information on how licensing works with your local distributor, please contact them via the details available on the 'contact' pages of the Matrix website: www.matrixtsl.com/

User type

The first step is for you to outline the 'type of user' you are. Users can be defined by either 'standard', which is suited to engineers who are home-users of Flowcode. Secondly, professional users are those who are looking to use Flowcode in a commercial environment.

Standard

A 'standard' user of Flowcode is someone who wishes to develop applications at home. A standard user licence does not give the user commercial rights; commercial rights can only be achieved by purchasing a professional Flowcode licence.

Professional

A 'professional' Flowcode user is someone who is using Flowcode code in commercial products or is working in a commercial environment. These type of users must select a professional licence.

Academic

Academic licences are available to Schools/Colleges/Teachers and Students. Available in 1, 10 and 50 user versions with large discounts. Academic pricing can only be found by contacting Matrix, or your local distributor direct. All academic licences are perpetual, meaning users do not have to pay an annual fee for their licence.

Device selection

Next, users must select the 'devices' they wish to be supported in their Flowcode licence. Of course, the free version of Flowcode will give a handful of target devices to the user without a charge, but this section gives the user the ability to select a vast range of supported devices, from your favourite microcontroller family.



8 bit PIC



16 bit PIC



32 bit PIC



AVR /Arduino



ARM

Users

If you are a professional or academic user, you can secure a number of multiple user licence options with your Flowcode licence. For professional users, you can select 2 or 5 licences at a discount price. Academic users can select from 10 or even 50 user site licences, again at a discounted price.

1 - 2 - 5 - 10 - 50



Features

Next, users select the features that they wish their Flowcode licence to include. The feature packs below are all optional with standard and professional Flowcode licences, but are supplied as standard with the academic version of Flowcode.

Comms pack A	Comms pack B	Display pack	DSP pack	Input / output pack
Contains a number of components for common chip-to-chip communications protocols. These include: I2C, MIDI, One Wire, RS232, SPI, UART, CAN, DALI, DMX_512, LIN, Modbus Master.	Contains components to perform wireless, USB and web-based communications. These include: TCP/IP, USB HID, USB Serial, USB Slave, Webserver, Bluetooth, WLAN, GSM, GPS, RfID, Zigbee	Allows developers to use Display components for a wide range of graphical and alpha-numeric LCDs. These include: GLCD - EB043, EB057, EB075, ILI9341, KS0108, SSD1289, SSD1305, SSD1306, SSD1322, SSD1351, ST7036, ST765R, ST7567, T6963C. Also LCD – AdafruitOLED, Generic	Gives access to the Flowcode DSP components, including Control, Delay, DSP System, Fast Fourier Transform {FFT}, Filter, Frequency Generator, Input, Level, Output, Scale, Sum.	Gives access to a range of input and output {I/O} devices. These include Potentiometer, Rotary Encoder, Thermistor base, 7Segment{Quad}, Dashboard lamp, Keypad, LED {various}, LED Array, LED Matrix, Microswitch, PWM, Switch {various}, Touch pads
Mechatronics pack	Misc pack A	20x4, Generic, I2C, 4x20 AdafruitOLED.		
This pack contains a range of motors and other electromechanical	This pack contains a range of motors and other electromechanical			
devices within Flowcode, including	devices within Flowcode, including	Ghost facilities	Simulation pack	
3D Printer, G Code Parser, Motor (Full Bridge), Motor (Half Bridge), Photo Reflector, Photo Transistor, Servo Controller, Servo Base, Solenoid Base, Solenoid DC1, Servo, Stepper Generic,	3D Printer, G Code Parser, Motor (Full Bridge), Motor (Half Bridge), Photo Reflector, Photo Transistor, Servo Controller, Servo Base, Solenoid Base, Solenoid DC1, Servo, Stepper Generic,	Unlocking this pack will give the developer access to the debugging features of Flowcode such as Code Profiling and Ghost technology (In Circuit Debug and In Circuit Test), including the Data Recorder and	These educational simulations have been built by our own engineers and model real world systems, such as an adjustable car seat, conveyor belt and aircraft landing gear.	

Upgrades

Stepper Base

Stepper Base

Users of Flowcode 5 and Flowcode 6 will receive handsome upgrade discounts to Flowcode 7. If you're a Matrix customer, you can purchase direct from us by putting your version 5 or 6 licence key into the Flowcode purchasing pages on our website.

Oscilloscope features.

Alternatively, you can purchase Flowcode upgrades with the discount applied from your local distributor

ACTIVATION

Each product will need activation with a code issued by Matrix. An internet connection is required for this.

UPGRADE RIGHTS

Upgrade rights do not apply to all versions of Flowcode. If your version of Flowcode has been included free of charge with MIAC or other hardware systems then upgrade rights might not apply.



Flowcode 7 components



www.matrixtsl.com/flowcode 16

"" String Translator



PIC 8 10F200, 10F202, 10F204, 10F206, 10F220, 10F222, 10F320, 10F322, 10LF320, 10LF322, 12C508, 12C508A, 12C509A 12C671, 12C672, 12CE518, 12CE519, 12CE673, 12CE674, 12F1571, 12F1572, 12F1612, 12F1822, 12F1840, 12F508, 12F509, 12F510, 12F609, 12F615, 12F617, 12F629, 12F635, 12F675, 12F683, 12HV609, 12HV615, 12LF1571, 12LF1572, 12LF1612, 12LF1822, 12LF1840, 16C716, 16C717, 16C72, 16C72A 16C73, 16C73A, 16C73B, 16C74, 16C74A, 16C74B, 16C76, 16C77, 16C770, 16C771, 16C773, 16C774, 16C84, 16C923, 16C924, 16CR72 16CR83, 16CR84, 16F1454, 16F1455, 16F1459, 16F1503, 16F1507, 16F1508, 16F1509, 16F1613, 16F1614, 16F1615, 16F1618, 16F1619, 16F1764, 16F1765, 16F1768, 16F1769, 16F1784, 16F1786, 16F1787 16F1788, 16F1789, 16F1823 16F1824, 16F1825, 16F1826, 16F1827 16F1828 16F1829 16F18313, 16F18323, 16F18324 16F18325, 16F18344, 16F18345 16F1847, 16F18854, 16F18855, 16F18856, 16F18857, 16F18875, 16F18876, 16F18877, 16F1933, 16F1934, 16F1936, 16F1937, 16F1938 16F1939 16F1946 16F1947, 16F505, 16F506, 16F527, 16F610, 16F616, 16F627, 16F627A, 16F628, 16F628A, 16F630, 16F631, 16F636, 16F639, 16F648A, 16F676 16F677, 16F684, 16F685, 16F687, 16F688, 16F689, 16F690, 16F707 16F716, 16F72, 16F722, 16F723, 16F724, 16F726, 16F727, 16F73, 16F737, 16F74, 16F747, 16F76, 16F767, 16F77, 16F777, 16F785, 16F818, 16F819, 16F83, 16F84, 16F84A, 16F87, 16F870, 16F871 16F872, 16F873, 16F873A, 16F874 16F874A, 16F876, 16F876A 16F877, 16F877A, 16F88, 16F882 16F883, 16F884, 16F886, 16F887, 16F913, 16F914, 16F916, 16F917, 16F946, 16LF1454, 16LF1455, 16LF1459, 16LF1507, 16LF1508, 16LF1509, 16LF1613, 16LF1614, 16LF1615, 16LF1618, 16LF1619, 16LF1764, 16LF1765 16| F1768 16| F1769 16| F1784 16LF1786, 16LF1787, 16LF1788 16LF1789, 16LF1823, 16LF1824 16LF1825, 16LF1826, 16LF1827, 16LF1828, 16LF1829, 16LF18313, 16LF18323, 16LF18324, 16LF18325 16LF18344, 16LF18345, 16LF1847 16LF18854, 16LF18855, 16LF18856 16LF18857, 16LF18875, 16LF18876, 16LF18877, 16LF1902, 16LF1903, 16LF1904, 16LF1906, 16LF1907, 16LF1933, 16LF1934, 16LF1936, 16I F1937, 16I F1938, 16I F1939, 16LF1946, 16LF1947, 16LF627, 16LF627A, 16LF628, 16LF628A 16LF648A, 16LF707, 16LF722, 16LF724, 16LF724, 16LF726, 16LF727, 16LF74, 16LF747, 16LF76, 16LF767, 16LF74, 16LF747, 16LF818, 16LF819, 16LF83, 16LF84, 16LF84A, 16LF87, 16LF870, 16LF871, 16LF872 16I F873, 16I F873A, 16I F874, 16LF874A, 16LF876, 16LF876A 16LF877, 16LF877A, 16LF88, 18F1220, 18F1230, 18F1320, 18F1330, 18F13K22, 18F13K50, 18F14K22, 18F14K50, 18F2220, 18F2221, 18F2320, 18F2321, 18F2331, 18F23K20. 18F23K22 18F2410, 18F242, 18F2420, 18F2423, 18F2431, 18F2439, 18F2450, 18F2455, 18F2458, 18F248, 18F2480, 18F24J10, 18F24J11, 18F24J50, 18F24K20, 18F24K22, 18F24K50, 18F2510, 18F2515, 18F252, 18F2520, 18F2523, 18F2525, 18F2539, 18F2550, 18F2553, 18F258, 18F2580, 18F2585, 18F25J10, 18F25J11, 18F25J50, 18F25K20 18F25K22, 18F25K50, 18F25K80,

18F2610, 18F2620, 18F2680, 18F2682, 18F2685, 18F26J11, 18F26J13, 18F26J50, 18F26J53 18F26K20, 18F26K22, 18F26K80, 18F27J13, 18F27J53, 18F4220, 18F4221, 18F4320, 18F4321 18F4331 18F43K20 18F43K22 18F4410, 18F442, 18F4420, 18F4423, 18F4431, 18F4439, 18F4450, 18F4455, 18F4458, 18F44K22, 18F4510, 18F4515, 18F452, 18F4520, 18F4523, 18F4525, 18F4539, 18F4550, 18E4553 18E458 18E4580 18F4585, 18F45J10, 18F45J11, 18F45J50, 18F45K20, 18F45K22, 18F45K50, 18F45K80, 18F4610, 18F4620, 18F4680, 18F4682, 18F4685, 18F46J11, 18F46J13 18F46J50, 18F46J53, 18F46K20, 18F46K22, 18F46K80, 18F47J13 18F47J53, 18F6310, 18F6390, 18F6410, 18F6490, 18F6520, 18F6527, 18F6585, 18F65J10, 18F65J15, 18F65J50, 18F65K22, 18F65K80, 18F6620, 18F6622, 18F6627, 18F6680, 18F66J10, 18E66111 18E66115 18E66116 18F66J50, 18F66J55, 18F66J60 18F66J65, 18F66J90, 18F66J93 18F66K22, 18F66K80, 18F6720, 18F6722, 18F67J10, 18F67J11, 18F67J50, 18F67J60, 18F67J90, 18F67J93, 18F67K22, 18F8310, 18F8390, 18F8410, 18F8490, 18F8520, 18F8527, 18F8585, 18F85J10, 18F85J15, 18F85J50, 18F85K22, 18F8620, 18F8622, 18F8627, 18F8680, 18F86J10, 18F86J11, 18F86J15, 18F86J16, 18F86J50, 18F86J55, 18F86J60 18F86J65, 18F86J90, 18F86J93, 18F86K22, 18F8720, 18F8722, 18F87J10, 18F87J11, 18F87J50 18F87J60, 18F87J90, 18F87J93 18F87K22, 18F96J60, 18F96J65 18F97J60, 18LF1220, 18LF1230, 18LF1320, 18LF1330, 18LF13K22 18I F13K50, 18I F14K22, 18I F14K50 8LF2220, 18LF2221, 18LF2320 18I F2321, 18I F2331, 18I F23K22 18LF2410, 18LF242, 18LF2420, 18LF2423, 18LF2431, 18LF2439, 18LF2450, 18LF2455, 18LF2458, 18LF248, 18LF2480, 18LF24J10, 18LF24J11, 18LF24J50, 18LF24K22, 18LF24K50, 18LF2510, 18LF2515, 181 F252 181 F2520 181 F2523 18LF2525, 18LF2539, 18LF2550, 181 F2553 181 F258 181 F2580 18LF2585, 18LF25J10, 18LF25J11, 18LF25J50, 18LF25K22, 18LF25K50, 18LF25K80, 18LF2610, 18LF2620, 18LF2680, 18LF2682, 18LF2685, 18LF26J11, 18LF26J13, 18LF26J50 18LF26J53, 18LF26K22, 18LF26K80, 18LF27J13, 18LF27J53, 18LF4220, 18LF4221, 18LF4320, 18LF4321, 18LF4331, 18LF43K22, 18LF4410, 18LF442, 18LF4420, 18LF4423, 18LF4431, 18LF4439, 18LF4450, 18LF4455, 18LF4458, 18LF448, 18LF4480, 18LF44J10, 18LF44J11 18LF44J50, 18LF44K22, 18LF4510, 18LF4515, 18LF452, 18LF4520, 18LF4523, 18LF4525, 18LF4539, 18LF4550, 18LF4553, 18LF458, 18LF4580, 18LF4585, 18LF45J10, 18LF45J11, 18LF45J50, 18LF45K22 18LF45K50, 18LF45K80, 18LF4610, 18LF4620, 18LF4680, 18LF4682, 8LF4685, 18LF46J11, 18LF46J13, 18LF46J50, 18LF46J53, 18LF46K22, 18LF46K80, 18LF47J13, 18LF47J53, 18LF6310, 18LF6390, 18LF6410, 18LF6490, 18LF6520, 18LF6527, 18LF6585, 18LF65K80, 18LF6620 18LF6622, 18LF6627, 18LF6680, 18LF66K80, 18LF6720, 18LF6722 181 F8310 181 F8390 181 F8410 18LF8490, 18LF8520, 18LF8527, 18LF8585, 18LF8620, 18LF8622, 18LF8627, 18LF8680, 18LF8720, 18LF8722, ECIO-28, ECIO-40, Formula Flowcode Buggy.

Locktronics PIC, Matrix Project Board (18F24K50), Matrix Proto Board (18F24K50), MIAC System, MIAC V2, MIAC, Microchip FSUSB, Microchip PIC18 SK, RF12F675F, RF12F675H, RF12F675K

PIC 16

24EP128GP202, 24EP128GP204, 24EP128GP206, 24EP128MC202 24EP128MC204, 24EP128MC206 24EP256GP202, 24EP256GP204, 24EP256GP206, 24EP256GU810 24FP256GU814 24FP256MC202 24EP256MC204, 24EP256MC206, 24EP32GP203, 24EP32GP203, 24EP32GP204, 24EP32MC202, 24EP32MC203, 24EP32MC204, 24EP512GP806, 24EP512GU810, 24EP512GU814, 24EP64GP202 24EP64GP203, 24EP64GP204, 24EP64GP206, 24EP64MC202, 24EP64MC203, 24EP64MC204, 24EP64MC206, 24F08KA101, 24F08KA102, 24F16KA101, 24F16KA102, 24F16KA301, 24F16KA302, 24F16KA304, 24F32KA301, 24F32KA302, 24F32KA304, 24FJ128DA106, 24FJ128DA110, 24FJ128DA206 24FJ128DA210, 24FJ128GA006, 24FJ128GA008, 24FJ128GA010, 24FJ128GA106, 24FJ128GA108, 24FJ128GA110, 24FJ128GB106, 24FJ128GB108, 24FJ128GB110, 24FJ128GB206, 24FJ128GB210 24FI16GA002 24FI16GA004 24FJ192GA106, 24FJ192GA108 24FJ192GA110, 24FJ192GB106, 24FJ192GB108, 24FJ192GB110, 24FJ256DA106, 24FJ256DA110, 24FJ256DA206, 24FJ256DA210, 24FJ256GA106, 24FJ256GA108, 24FJ256GA110, 24FJ256GB106, 24FJ256GB108, 24FJ256GB110 24FJ256GB206, 24FJ256GB210, 24FJ32GA002, 24FJ32GA004, 24FJ32GA102, 24FJ32GA104, 24FJ32GB002, 24FJ32GB004, 24FJ48GA002, 24FJ48GA004, 24FJ64GA002, 24FJ64GA004, 24FJ64GA006, 24FJ64GA008 24FJ64GA010, 24FJ64GA102, 24FJ64GA104, 24FJ64GB002, 24FI64GB004, 24FI64GB106 24FJ64GB108, 24FJ64GB110, 24FJ96GA006, 24FJ96GA008, 24FJ96GA010, 24FV16KA301, 24FV16KA302, 24FV16KA304 24FV32KA301, 24FV32KA302, 24FV32KA304, 24HJ128GP202 24HJ128GP204, 24HJ128GP206, 24HJ128GP206A, 24HJ128GP210, 24HJ128GP210A, 24HJ128GP306, 24HJ128GP306A, 24HJ128GP310, 24HJ128GP310A, 24HJ128GP502 24HJ128GP504, 24HJ128GP506, 24HJ128GP506A, 24HJ128GP510, 24HJ128GP510A, 24HJ128GP802 24HJ128GP804, 24HJ12GP201, 24HJ12GP202, 24HJ16GP304, 24HJ256GP206, 24HJ256GP206A 24HJ256GP210, 24HJ256GP210A, 24HJ256GP610, 24HJ256GP610A, 24HJ32GP202, 24HJ32GP204, 24HJ32GP302, 24HJ32GP304, 24HJ64GP202, 24HJ64GP204, 24HJ64GP206, 24HJ64GP206A 24HJ64GP210, 24HJ64GP210A, 24HJ64GP502, 24HJ64GP504, 24HJ64GP506A, 24HJ64GP506, 24HJ64GP506A, 24HJ64GP510, 24HJ64GP510A 24HJ64GP802, 24HJ64GP804, 30F1010, 30F2010, 30F2011, 30F2012, 30F2020, 30F2023, 30F3010, 30F3011, 30F3012, 30F3013, 30F3014, 30F4011, 30F4012, 30F4013, 30F5011, 30F5013, 30F5015, 30F5016 30F6010. 30F6010A, 30F6011, 30F6011A, 30F6012, 30F6012A 30F6013, 30F6013A, 30F6014, 30F6014A, 30F6015, 33EP128GP502, 33EP128GP504, 33EP128GP506, 33EP128MC202,

33EP128MC204, 33EP128MC206, 33EP128MC504, 33EP128MC504,

33EP128MC506, 33EP256GP502 33EP256GP504, 33EP256GP506, 33EP256MC202, 33EP256MC204, 33EP256MC206, 33EP256MC502, 33EP256MC504, 33EP256MC506, 33EP256MU806, 33EP256MU810, 33FP256MLI814_33FP32GP502 33EP32GP503, 33EP32GP504, 33EP32MC202, 33EP32MC203 33EP32MC204, 33EP32MC502 33EP32MC503, 33EP32MC504, 33EP512GP806, 33EP512MC806, 33EP512MU810, 33EP512MU814 33EP64GP502, 33EP64GP503, 33EP64GP504, 33EP64GP506, 33EP64MC202, 33EP64MC203, 33EP64MC204, 33EP64MC206, 33EP64MC502, 33EP64MC503, 33EP64MC504, 33EP64MC506, 33FJ06GS101, 33FJ06GS102, 33FJ06GS202, 33FJ128GP202, 33FJ128GP204, 33FJ128GP206 33FJ128GP206A, 33FJ128GP306 33FJ128GP306A, 33FJ128GP310 33FJ128GP310A, 33FJ128GP706, 33FJ128GP706A, 33FJ128GP708 33FJ128GP708A, 33FJ128GP710, 33FJ128GP710A, 33FJ128GP802, 33FJ128GP804, 33FJ128MC202, 33FI128MC204 33FI128MC506 33FJ128MC506A, 33FJ128MC510, 33FJ128MC510A, 33FJ128MC706, 33FJ128MC706A, 33FJ128MC708, 33FJ128MC708A, 33FJ128MC710, 33FJ128MC710A, 33FJ128MC802, 33FJ128MC804, 33FJ12GP201, 33FJ12GP202, 33FJ12MC201, 33FJ12MC202, 33FJ16GP304 33FJ16GS402, 33FJ16GS404, 33FJ16GS502, 33FJ16GS504, 33FJ16MC304, 33FJ256GP506, 33FJ256GP506A, 33FJ256GP506A, 33FJ256GP506A, 33FJ256GP510, 33FJ256GP510A, 33FJ256GP710, 33FJ256GP710A, 33FJ256MC510, 33FJ256MC510A, 33FJ256MC710, 33FJ256MC710A, 33FJ32GP202, 33FJ32GP204, 33FJ32GP302, 33FJ32GP304, 33FJ32GS406, 33FJ32GS606, 33FJ32GS608, 33FJ32GS610, 33FJ32MC202, 33FJ32MC204, 33FJ32MC302, 33FJ32MC304, 33FJ64GP202 33FI64GP204, 33FI64GP206, 33FJ64GP206A, 33FJ64GP306, 33FJ64GP306A, 33FJ64GP310, 33FJ64GP310A, 33FJ64GP706, 33FJ64GP706A, 33FJ64GP708, 33FJ64GP708A, 33FJ64GP710, 33FJ64GP710A, 33FJ64GP802, 33EI64GP804 33EI64GS406 33FJ64GS606, 33FJ64GS608, 33FI64GS610_33FI64MC202 33FJ64MC204, 33FJ64MC506, 33FJ64MC506A, 33FJ64MC508, 33FJ64MC508A, 33FJ64MC510, 33FJ64MC510A, 33FJ64MC706, 33FJ64MC706A, 33FJ64MC710, 33FJ64MC710A, 33FJ64MC802 33FJ64MC804, FB091, FCIO40P16 Formula Allcode, MIAC (dsPIC) System, MIAC (dsPIC)

PIC32

32MX110F016B, 32MX110F016C, 32MX110F016D, 32MX120F032B, 32MX120F032C, 32MX120F032D, 32MX120F064H, 32MX130F064B, 32MX130F064C, 32MX130F064D, 32MX130F128H, 32MX130F128L, 32MX130F256B, 32MX130F256D, 32MX150F128B, 32MX150F128C, 32MX150F128D, 32MX150F256H 32MX150F256L, 32MX170F256B 32MX170F256D, 32MX170F512H, 32MX170F512L, 32MX210F016B, 32MX210F016C, 32MX210F016D, 32MX220F032B, 32MX220F032C, 32MX220F032D, 32MX230F064B, 32MX230F064C, 32MX230F064D, 32MX230F128H 32MX230F128L 32MX230F256B, 32MX230F256D 32MX250F128B 32MX250F128C 32MX250F128D, 32MX250F256H, 32MX250F256L, 32MX270F256B, 32MX270F256D, 32MX270F512H, 32MX270F512L, 32MX320F032F 32MX320F064H, 32MX320F128H,

Flowcode 7 target specifications 32MX320F128L, 32MX330F064H, 32MX330F064L, 32MX340F128H, 32MX340F128L, 32MX340F256H, 32MX340F512H, 32MX350F128H 32MX350F128L, 32MX350F256H, 32MX350F256L, 32MX360F256L, 32MX370F512L, 32MX420F032H, 32MX430F064H, 32MX430F064L 32MX440F128H, 32MX440F128L, 32MX440F256H, 32MX440F512H, 32MX450F128H, 32MX450F128L, 32MX450F256H, 32MX450F256L, 32MX460F256L, 32MX460F256L, 32MX460F512L, 32MX470F512H, 32MX470F512L 32MX530F128H, 32MX530F128L 32MX534F064H, 32MX534F064L, 32MX550F256H, 32MX550F256L, 32MX564F064H, 32MX564F064H, 32MX564F128H, 32MX564F128L, 32MX570F512H, 32MX570F512L 32MX575F256H, 32MX575F256L 32MX575F512H, 32MX575F512L 32MX664F064H, 32MX664F064L, 32MX664F128H, 32MX664F128L, 32MX675F256H, 32MX675F256L, 32MX675F512H, 32MX675F512L, 32MX695F512H, 32MX695F512L, 32MX764F128H, 32MX764F128L 32MX775E256H 32MX775E256L 32MX775F512H, 32MX775F512L, 32MX795E512H 32MX795E512L 32MZ0512EFE064 32M71024FCG064 32MZ1024ECG100, 32MZ1024ECG124 32MZ1024ECG144. 32MZ1024ECH064 32M71024ECH100 32MZ1024ECH124, 32M71024FCH144 32MZ1024ECM064

> 32MZ1024EFF124 32M71024FFF144 32MZ1024EFG064 32M71024FFG100 32MZ1024EFG124 32M71024FFG144 32MZ1024EFH064, 32MZ1024EFH100 32M71024FFH124 32MZ1024EFH144 32M71024FFK064 32MZ1024EFK100, 32M71024FFK124 32MZ1024EFK144, 32MZ1024EFM064 32MZ1024EFM100. 32MZ1024EFM124 32M71024FFM144 32MZ2048ECG064, 32M72048ECG100 32MZ2048ECG124 32MZ2048ECG144 32M72048FCH064 32MZ2048ECH100 32M72048FCH124 32MZ2048ECH144 32M72048FCM064 32MZ2048ECM100, 32M72048FCM124 32MZ2048ECM144, 32MZ2048EFG064 32M72048FFG100 32MZ2048EFG124, 32M72048FFG144 32MZ2048EFH064 32M72048FFH100 32MZ2048EFH124, 32MZ2048EFH144, 32MZ2048EFM064 32MZ2048EFM100, 32M72048FFM124 32MZ2048EFM144

32MZ1024ECM100, 32MZ1024ECM124,

32MZ1024ECM144

32M71024FFF064

32MZ1024EFE100,

32M71024FFF124

32MZ1024EFE144,

32MZ1024EFF064, 32MZ1024EFF100,



AVR

Arduino BT 168, Arduino BT 328, Arduino Duemilanove 168, Arduino Duemilanove 328P, Arduino Duemilanove168P, Arduino Ethernet, Arduino EtherTen, Arduino Fio, Arduino Leonardo, Arduino LilyPad 168, Arduino LilyPad 328, Arduino LilyPad Simple and Simple Snap, Arduino LilyPad Usb, Arduino Mega 1280, Arduino Mega 2560 R3, Arduino Mega 2560, Arduino Mega ADK 2560 R3, Arduino Mega ADK 2560, Arduino Micro, Arduino Mini, Arduino Nano 168, Arduino Nano 328, Arduino Pro 168 3V3, Arduino Pro 168 5V, Arduino Pro 328 3V3, Arduino Pro 328 5V, Arduino Pro Mini 3V3, Arduino Pro Mini 5V, Arduino RFu-328, Arduino Trinket, Arduino Uno PDIP, Arduino Uno R3 PDIP, Arduino Uno R3 SMD, Arduino Uno Uno R3 SMD, Arduino Uno SMD, Arduino XinoRF, Arduino Yun, AT90CAN128, AT90CAN32, AT90CAN64, AT90PWM1, AT90PWM2, AT90PWM216, AT90PWM2B, AT90PWM3, AT90PWM316, AT90PWM3B, AT90PWM81, AT90S2313, AT90S2323, AT90S2333, AT90S2343, AT90S4414, AT90S4433, AT90S4434, AT90S8515, AT90S8535, AT90USB1286, AT90USB1287, AT90USB1286, AT90USB1287 AT90USB646, AT90USB646, AT90USB647, AT90USB82, ATMEGA103, ATMEGA128, ATMEGA1280, ATMEGA1281, ATMEGA1284P, ATMEGA16, ATMEGA163, ATMEGA162, ATMEGA163, ATMEGA164A, ATMEGA164P, ATMEGA165, ATMEGA165P, ATMEGA168, ATMEGA168P, ATMEGA169, ATMEGA169P, ATMEGA16A, ATMEGA16M1, ATMEGA16U2, ATMEGA16U4, ATMEGA2560, ATMEGA2561, ATMEGA32, ATMEGA323, ATMEGA324A, ATMEGA324P, ATMEGA325, ATMEGA3250, ATMEGA3250P, ATMEGA325P, ATMEGA328, ATMEGA328P, ATMEGA328PTQFP, ATMEGA328TQFP, ATMEGA329, ATMEGA3290, ATMEGA3290P, ATMEGA329P, ATMEGA32C1 ATMEGA32M1, ATMEGA32U2 ATMEGA32U4, ATMEGA32U4, ATMEGA32U4, ATMEGA32U6, ATMEGA406, ATMEGA48, ATMEGA48P, ATMEGA64, ATMEGA640, ATMEGA644, ATMEGA644P, ATMEGA645, ATMEGA6450, ATMEGA6450P, ATMEGA645P, ATMEGA645P, ATMEGA649, ATMEGA6490, ATMEGA6490P, ATMEGA649P, ATMEGA64C1, ATMEGA649P, ATMEGA64C1, ATMEGA64M1, ATMEGA8, ATMEGA8515, ATMEGA8535, ATMEGA88, ATMEGA88P, ATMEGA8U2, ATTINY13, ATTINY167, ATTINY22, ATTINY2313, ATTINY24, ATTINY25, ATTINY261, ATTINY4313, ATTINY44, ATTINY45, ATTINY461, ATTINY48, ATTINY84, ATTINY85, ATTINY861, ATTINY87, ATTINY88, ATXMEGA128A1, ATXMEGA128A3, ATXMEGA128D3, ATXMEGA16A4, ATXMEGA16D4, ATXMEGA192A3, ATXMEGA192D3, ATXMEGA256A3, ATXMEGA256A3, ATXMEGA256A3B, ATXMEGA256D3, ATXMEGA32A4, ATXMEGA32D4, ATXMEGA64A1, ATXMEGA64A3, ATXMEGA64D3 MIAC (Arduino-Compatible) System, MIAC (Arduino-Compatible)

ARM

AT91SAM7S128 AT91SAM7S128_64 AT91SAM7S16 AT91SAM7S161 AT91SAM7S16_64 AT91SAM7S256 AT91SAM7S256_64 AT91SAM7S32 AT91SAM7S321 AT91SAM7S321 64 AT91SAM7S32_64 AT91SAM7S512 AT91SAM7S512_64 AT91SAM7S64 AT91SAM7S64_64 AT91SAM7S64_EK AT91SAM7SE256 AT91SAM7SE32 AT91SAM7SE512 EB031 ECIOARM



Matrix Technology Solutions Limited
The Factory
33 Gibbet Street
Halifax HX1 5BA
United Kingdom

t: +44 (0) 1422 252380 f: +44 (0) 1422 341830 e: sales@matrixtsl.com



www.matrixtsl.com